


# Wizard Firmware Update for Windows


## To update Wizard firmware via Firmware Update:

If your computer doesn't have the USB driver installed, please find the latest version here and download the installer for the STM32 Virtual COM port driver. Install the driver according to your operating system, then restart the computer.

**STEP 1)** Open Firmware Update, tap [...] on the top right of interface window.





**STEP 2)** A program window comes out. Select the wizard firmware file that needs to be updated.



**STEP 3)** Connect Wizard with your computer via a micro USB cable. Press and hold Start/Stop Button, then press and hold Power Button. GPS LED will glow green and then Aircraft Mode LED turns blue. Flash process will begin automatically with Aircraft Mode LED flashes blue and red, now you can release both buttons.

**IMPORTANT NOTE:** The firmware file need to be downloaded from here and save it to your computer first.



1. Aircraft Mode LED
2. GPS LED
3. Start / Stop Button
4. Power Button

**STEP 4)** After update succeed, the interface is as below. If update fail, disconnect wizard from your computer and go back to STEP 2.

